


Metal Saw




Makita

2414NB






65010

Metal Saw




→ To be checked.

Operating instruction


Tasks in order	Description	Picture
To fix the object on the plate	Use the vice, to firmly fix your object.	
To check the saw	Check if the circular saw is well fixed, and that the blade is not damaged.	
To plug in the saw	Plug in the saw to the single phase electricity.	
To make the saw rotate	Press the black button with your index finger to speed up the rotation of the saw	
To cut	Push the handle at the same time as pressing the black button until the contact with the metal materials, cut your piece with a small pressure on the handle.	
To stop	Bring back the handle to the top, press the black button and unplug the saw.	



HEALTH & SAFETY



HAVE TO BE WORN TO USE THIS MACHINE :



Protective
clothing



Safety footwear



Eye protection

Carry out the maintenance as mentioned in the manual's instructions.

In case of accident or of a discovery of someone in difficulty:

- Contact Green Skip : **21422009** (from inside of the company : 111)
- In case of absence: 21422010/21422017

- 1) Call the emergency general number typing the number



112 or for the ambulance 196.

- 2) Give the address of the place: **GREEN SKIP GROUP SERVICES LTD, Ta' I imriekeb, Ramla road, Maghtab-Naxxar, NXR 6540, MALTA**, explaining the entrance and the floor of the building where the people to save are.
- 3) Go to welcome the emergency services at the address you told them.

SAFETY INSTRUCTIONS :

Keep hands away from cutting area and blade. Keep your second hand on auxiliary handle, or motor housing. If both hands are holding the saw, they cannot be cut by the blade. Hold the saw firmly to prevent loss of control.

1. Wear safety glasses, goggles or a face shield at all times while using the saw.
2. If the cutting operation is dusty, wear a dust mask.
3. Do not wear gloves while operating a table saw.
4. Avoid long sleeves, ties, dangling jewelry or any other loose fitting clothing while operating a table saw. The clothing could get caught in the blade.
5. Wear non-slip footwear.
6. Use a stop block when you crosscut short lengths.
7. Position your body so that it is NOT in line with the blade. This is to avoid being injured by flying sawdust, woodchips or the work.
8. Always stand firmly on the floor and avoid any awkward operations. This is to avoid falling into the blade by slipping or losing your balance.
9. Do not carry on a conversation while cutting. Pay attention to the work being performed.
10. Do not reach behind or under the blade unless it has stopped turning.
11. Do not leave the saw until the blade has come to a complete stop.
12. Always disconnect the power prior to changing the blade or performing any other maintenance operation.
13. Make sure that the blade has stopped turning before you adjust the table saw.
14. After any adjustment, make sure that the blade is free before you turn on the power.
15. Check that the stock has no nails, knots screw, stones etc. in it prior to cutting. These items can become projectiles and cause injury.

MAINTENANCE :

Every 6 Months : Sharpen the blades

Every use : Always keep tool and cord clean (especially the ventilation slots) **disconnect the plug before cleaning.** Clean saw blade immediately after use (especially from resin and glue)

Schedule of Maintenance:

Note down every time you use the machine and what kind of maintenance was carried out as mentioned in the manual's instructions.

NAME/DATE	Maintenance carried done	When is the next date for the same maintenance?