

Annex D – method statement for degassing operations

This method statement is based on the operating manual [REDACTED] as applicable to degassing operations. The following sequence must be followed:

- A. Ensure that degassing equipment is in good operating order, and connected to a power supply. Refer to operating manual in case of any difficulty or malfunction to rectify issue. Ensure that safety rules stipulated in the manual are followed.
- B. Connect the recovery hoses to the vehicle A/C system with the quick connect couplings.
- C. Run the vehicle engine with the air conditioner on, and the fan at full speed.
- D. Switch off the engine, keeping the A/C running if possible.
- E. Open the high and low pressure taps.
- F. Hold the SEL key until 'Recovery' is indicated in the LED display, and record the amount of refrigerant recovered (units used in display are kg). Halting and oil recovery are automatic.
- G. Switch off the vehicle A/C fan and disconnect the degassing equipment.