

MRF Daily Cleaning / Maintenance Checklist

Site: MRF RSL

Date: _____

MRF RSL Blower Current: _____ A (Acceptable Range: 43A - 45A)

Frequency: Daily

Kindly tick the appropriate box.

Area	Done	Not Done	Comments
Platform	<input type="checkbox"/>	<input type="checkbox"/>	
Rollers	<input type="checkbox"/>	<input type="checkbox"/>	
Scrapers	<input type="checkbox"/>	<input type="checkbox"/>	
Empty Bag Opener	<input type="checkbox"/>	<input type="checkbox"/>	
Floor Around the Bag Opener	<input type="checkbox"/>	<input type="checkbox"/>	
Cleaning of Conveyors	<input type="checkbox"/>	<input type="checkbox"/>	
Area in Front of Bunkers	<input type="checkbox"/>	<input type="checkbox"/>	
Cleaning of the DB from the outside	<input type="checkbox"/>	<input type="checkbox"/>	

Frequency: 1st of the Month

Kindly tick the appropriate box.

Area	Done	Not Done	Comments
RSL Blower: The HEPA filter is to be removed cleaned, inspected and re-installed in filter box	<input type="checkbox"/>	<input type="checkbox"/>	

Cleaning carried out by:

Name & Surname

Signature

Name & Surname

Signature

Name & Surname

Signature